

# Terason Trackball Cleaning instructions

1. Put the tip of a pen or pointy object in the trackball retainer ring right indentation. Push towards the back of the laptop to spin the ring in a counter-clockwise rotation.



2. The ring will disengage and start to lift. Gently remove the ring then remove the ball.



3. Moisten a cloth with rubbing alcohol or warm water. (\*Make sure it is mildly damp and not dripping with liquid). Clean the trackball itself then clean the clear plastics underneath thoroughly. Use a dry cloth to remove excess liquid and verify it is completely dry prior to reassembling.



4. Place the ball back in the bezel then insert the ring so the indents are diagonal to the computer as indicated in the picture. It should rest so it is almost flush with the bezel.



5. Secure the retainer ring into place by inserting the pen in the left indentation and pushing towards the back of the computer to spin the ring clockwise. It should lock back into place when the dots become parallel with the computer bezel.

